

Planet RH

The solution for wavy floors and all door models

Versions: silicone smoke-shielding (RD)

Mounting instructions: control knob on hinge side

- 1 Closing direction of the door:** *do not close against the bevel lip.
- 2 Clearance between door leaf and floor:** up to 25 mm.
- 3 Groove size:** at least 30–32 mm deep and 13,1 mm wide, removed as far as possible from the pivot (refer to fig. 2). The Planet RH must not jam in the groove.
- 4 Shorten:** Cut a clean surface on the lock side, at most up to the next shorter length (max. 125 mm) approx. 1 to 2 mm shorter than the dimension of the door folding. Remove any existing sawdust. For double wing folding doors or in case of narrow joint clearance shorten at released condition!
- 5 Fastening:** on both sides by a retaining triangle each. **Caution:** first prepare the pilot-drills, then hold the SPAX screws right during screwing in.
- 6 Stopping plate:** in case of wooden door frame, drive home the stopping plate into the center of the pressure mark.
- 7 Lift height adjustment:** it is achieved by rotating the control knob with a 3 mm Allen key. Refer to figure 2 for the final position of the control knob.
- 8 Adjustment:** adjust the Planet RH in such a way that the sealing blade fits close to the floor when door is closed. In case of sound absorbing doors: provide by all means a floor rail and a floor-level separation (e.g. Planet F or Planet BT).

