

#### Mounting instructions: control knob on hinge side

- 1 Clearance between door leaf and floor:** at least 5 mm up to max. 16 mm.
- 2 Seal position:** positioned in the 24 mm groove or the EURO groove with the fastening bracket (figure 2 and 3).
- 3 Planet RS, length determination:** the seal becomes longer by 5 mm on both sides by the special fastening bracket → this means the seal length is longer by 4 to 5 mm as the door leaf rebate measure (figure 2 and 3).
- 4 Shorten:** cut a clean surface on the lock side, at most up to the next shorter length (max. 125 mm). Remove any existing sawdusts.
- 5 Fastening:** the seal is fastened with the special fastening brackets on both sides by 2 screws each (furnished by customer).
- 6 Stopping plate:** fasten it on the jamb by a screw (furnished by customer) on the height of the release knob (figure 4).
- 7 Lift height adjustment:** it is achieved by rotating the control knob with a 3 mm Allen key. Refer to figure 5 for the final position of the control knob.
- 8 Adjustment:** adjust the Planet RS in such a way that the sealing blade fits close to the floor when the door is closed.  
In case of sound absorbing doors: provide in any case a floor rail and a floor separation (e.g. Planet F or Planet BT).

